















































Alcatel-Lucent 8068/8038/8028/8039/8029 Premium DeskPhone



Function Keys	
Mute and interphony	
Volume hands-free or headset	
Audio services (hands-free or handset)	
<ul style="list-style-type: none"> Programmable key (F1 and F2 keys): Lit when the function associated with the key is activated. A service or a direct call can be assigned to these keys Pre-programmed function keys are disabled in "safe" mode. The F1 and F2 keys are line keys 	
Redial key: Accesses the 'Redial' feature	
Guide key: Obtains information about "menu" page functions and "perso" page program keys	
Messaging key: Accesses various mail services. This key is lit when a new voice message, a new text message or a callback request is received	
Hands-free key: make or answer a call without lifting the receiver.	
END key: Terminates a call	
Bluetooth wireless handset (8068 Premium Deskphone)	
	Off-hook/On-hook  Volume/Mute:  <ul style="list-style-type: none"> Press quickly and repeat to change the handset volume (3 levels) Press and hold to ensure the phone is muted

Welcome screens			
	Contains several lines/pages of information about calls and the features that can be accessed by pressing the keys associated to the labels on the display (10 keys for 8068/38/39 phones or 6 keys for the 8028/29 phones). <ul style="list-style-type: none"> Menu page: Contains all functions and applications accessible with the keys associated with on-screen text Perso page: Contains call line keys (allowing call supervision) and programmable call keys Info page: Contains information on the telephone and the status of its functions: e.g., name, telephone number, number of messages, activation of transfer function, appointment reminder Transfer icon:  Pressing the key next to this icon allows the transfer function to be programmed or changed 		
Navigation			
	<ul style="list-style-type: none"> OK key: Confirms choices and options while programming or configuring Left-right navigator: Used to move from one page to another and to display information about current calls (call in progress, calls on hold, incoming call) Up-down navigator: Used to scroll through the content of a page 		
	Back/Exit key: Used to go back to the previous step		
Status icons/Call icons			
	Headset connected		Incoming call icon
	Telephone locked		Call in progress icon
	Appointment programmed		Call holding icon
Alphabetic keypad		Add-on modules	
Cursor control keys (left, right, up and down) 		The 8028 Premium Deskphone has 4 programmable keys with LED and paper labels. Phone capabilities can be extended with Premium Add-on 10- and 40-key modules or Premium Smart display 14-key module. 	
Caps lock: write text in capital letters 			
Alt key: accesses the alternate characters or features (in purple) 			
Enter key: confirms edited text 			
Backspace key: deletes one character in an edit box 			

All features are described for The Alcatel-Lucent OpenTouch™ Solution - OmniPCX™ Office Rich Communication Edition (RCE), OpenTouch Connection (OTCT). A feature is described twice if it operates differently according to the system. The label displayed on the phone depends on the type of phone. The guide lists the label of the 8068/38/39 phone with the labels of the 8028/29 listed in parenthesis, if different.

<p>Call</p> <ul style="list-style-type: none"> Dial the number directly or dial the number after pressing a line key (an off-hook key phone or Bluetooth handset, hands-free key) 	
<p>Call by name (company directory)</p> <ul style="list-style-type: none"> RCE - Enter the first letters of contact's name and follow the on-screen instructions OTCT - Enter the name, contact's surname/name or initials and follow the on-screen instructions 	
<p>Answer a call</p> <ul style="list-style-type: none"> Take the handset off the hook, use an off-hook key (phone or Bluetooth handset), use hands-free key, or press the key next to the incoming call icon 	
<p>Ignore call / End call</p>	
<p>Redial</p> <ul style="list-style-type: none"> Press and hold to access a list of the last 10 numbers dialed Press quickly and release to call the last dialed number 	
<p>Make a call-back request to a busy number</p> <ul style="list-style-type: none"> <i>Callback</i> 	
<p>Place a call on hold (hold)</p> <ul style="list-style-type: none"> <i>Hold</i> 	
<p>Send DTMF signals</p> <ul style="list-style-type: none"> <i>MF Code</i> (RCE), <i>Send DTMF</i> (OTCT) Send numbers 	
<p>Mute</p>	
<p>Interphony</p> <ul style="list-style-type: none"> The phone automatically answers the call A succession of specific beeps is played before the line is picked up 	
<p>Make a second call during a conversation</p> <ul style="list-style-type: none"> <i>New call</i> 	
<p>Answer a second call during a conversation</p> <ul style="list-style-type: none"> Press the key associated with the incoming call 	
<p>Switch between calls (broker call)</p> <ul style="list-style-type: none"> Press the key associated with the call on hold 	
<p>Cancel a second call and rejoin the first</p> <ul style="list-style-type: none"> Automatically rejoins the first call 	
<p>Transfer a call</p> <ul style="list-style-type: none"> While in conversation with one caller Call a second contact Transfer the call 	
<p>Conference</p> <ul style="list-style-type: none"> Call the first contact Call the second contact <i>Conference (Confer)</i> 	
<p>Add-on module</p> <ul style="list-style-type: none"> Press an unprogrammed key and follow the on-screen instructions 	Perso
<p>Modify the programmed key</p> <ul style="list-style-type: none"> Press the programmed key to be modified Follow the on-screen instructions 	Perso
<p>Erase a programmed key</p> <ul style="list-style-type: none"> <i>Settings</i> <i>Keys</i> Select the key to be erased Follow the on-screen instructions 	Menu 
<p>Customise the voice greeting</p> <ul style="list-style-type: none"> <i>Settings</i> <i>Mailbox (MlBox)</i> <p>Options: listen to the greeting, customize the greeting, set the default greeting</p>	Menu
<p>Call voicemail</p>	
<p>Forward calls to voicemail</p> <ul style="list-style-type: none"> Press the key associated with the forward icon <i>Immediate->VM (Immed -> VM)</i> Press the key associated with the type of call forward required 	
<p>Cancel forward</p> <ul style="list-style-type: none"> Press the key associated with the forward icon <i>Cancel fwd (Canc fwd)</i> 	
<p>Do not disturb</p> <ul style="list-style-type: none"> Press the key associated with the forward icon DoNotDisturb (DND) 	
<p>Send text messages</p> <ul style="list-style-type: none"> <i>Message</i> <i>Send TxtMsg (SendTxt)</i> Enter the destination number Select the type of message to send (fixed Msg, New Msg, b3&) 	
<p>Read text messages</p> <ul style="list-style-type: none"> <i>Message</i> <i>Read TxtMsg (ReadTxt)</i> 	
<p>Information about the phone</p>	Info
<p>Lock/unlock the phone</p> <ul style="list-style-type: none"> <i>Lock</i> 	Menu
<p>Adjust audio volume</p>	
<p>Select language</p> <ul style="list-style-type: none"> <i>Settings, Options</i> <i>Language (Lang)</i> 	Menu
<p>Choose the ring tone</p> <ul style="list-style-type: none"> <i>Ringing</i> <p>Adjust the ringtone with the following options: <i>Melody, Silent, Beeps, Volume, Progress ...</i></p>	Menu
<p>Adjust screen contrast</p> <ul style="list-style-type: none"> <i>Settings, Phone</i> <i>Contrast</i> 	Menu
<p>Change the password</p> <ul style="list-style-type: none"> <i>Settings</i> <i>Options</i> (OmniPCX Office), <i>Phone</i> (OmniPCX Enterprise) <i>Password</i> 	Menu
<p>Select the default on-screen homepage</p> <ul style="list-style-type: none"> <i>Settings, Options</i> <i>Homepage</i> Select the default page 	Menu